

# FOLLOW575 Instructions

## **Instructions:**

Set the follow spot on the stand and secure before connecting to power.

Plug the power cord in and turn on the power switch. The bulb will take a few minutes to reach full brightness.

Lever on top is aperture. Lever on right side is black out (but bulb stays on).

Manual color wheel selection on bottom (you actually turn the dichroic wheel with your finger).

Dichroic color wheel with red, blue, green, yellow, white.

**\*\*The color wheel gets very hot (because it is directly in front of a very hot bulb). You will need to wear gloves or a finger tip protector when turning the color wheel.\*\***

Power switch on back.